

Quick Start Guide

Management & Diagnostic Reports

Learn about:

- 1. Locating new management and diagnostic reports that are available on the Reports tab
- 2. Report descriptions
- 3. Generating a PDF version of a report

Locating Management & Diagnostic Reports

нс	OME SAMPLES	EQUIPMENT	LABELS	REPORTS	PREFERENCES	ADMIN	Quick Search
Management	Distributio	ne	1 1 K 1	MANAGE	MENT REPORTS		-3 mm
management				REPORT DI	ISTRIBUTIONS		

Management Reports



Transit Time Summary

ABCM	-						-
	***		_				_
10	_	_	_		_	_	
			-		-	-	_
							-
							_
							_
							-
							-
							_
							_
					-		
			-	14	-		-

Components With No Product In Use



Sample Volume by Worksite



Samples With No Sampled Date



Unregistered Units and Compone

Sample Volume by Worksite by Component

	-								•		-	
2.4	ACC.	HE				-					-	
_	-			_		_	_	-				
=	_	_	_	_	_	_	-	-	-	_	-	
-	1		-	-	-	-	12	v	24	-	-	
			-									
						-2.	-					
		-	-		-	-						
		-										
		-	_		-		-	-	-	-		
			_		-	_		-				
		-		-	-		-	-	-			
		-				-	-		-			
		-										
										_		
			-		-					-		
		-					-			200		
		-		-	-		-			100		
		-	-		-	-	-			-		
										-		

Samples With No Lube Age

diam'			• •	-	- 1			-	
LARCHE	KOA.				-	12			
			_		_		_	_	_
-									
-	-								
		-	-	-		-			
		4		١.					
		()					
		(0)					
		9)					
	812	()		-			
W 100	112		1)	10		275	-	14
10 mm	12	1	10		15	-	255	ala	14
10 mm			100		-	-			
	10	- 10	1		-	-			-
	100	- 10	100	-	-	-	-		-
			-	-		4 1 1	-		
100 mmm 100 mmm 100 mmm	1 1000		1		10 × × × ×	1 I I I I	-	1 1 1 1	

Sample Labels

Diagnostic Reports

ABCMICA	r -	-	
	_		
10	_		

Acceptable vs. Unacceptable - All Components



To access your management reports, click on the *Reports* tab and then select *Management Reports*. Next, click on the report you'd like to generate.

Management Report Descriptions (1 of 2)

Depending on your access level, Labcheck now offers management reports shown in the table below:

Transit Time	 Summarizes sample transit time for a given
Summary	time period
Sample Volume	 Details the number of samples completed for
by Worksite	worksites for a given time period
Sample Volume	 Details the number of samples completed for
by Worksite	worksites at the component level for a
by Component	given time period
Unregistered	 List of units and components with missing
Units and	registration information by worksite for a
Components	given time period

Components With No Products In Use	 Lists worksites, unit ID, component and last sample date for samples submitted with incorrect or no oil information submitted
Samples With No Sample Date	 Lists worksites, unit ID, component and sample-received date for samples received without a sample-taken date for a given time period
Samples With No Lube Age	 Lists worksites and samples (unit ID, component, sample date) for samples received without a lube age for a given time period
Sample Labels	 Displays the number of hand-written labels received vs. labels generated online by worksite for a given time period

Diagnostic Report Descriptions (1 of 2)

Depending on your access level, Labcheck now offers diagnostic reports shown in the table below:

Acceptable vs.	 Lists worksites and acceptable vs.
Unacceptable –	unacceptable samples for a given time
All Components	period
"A,B,C,D" Results	 Displays all severity results by worksite by
by Component	component for a given time period
All "D" Results	 Displays all "D" code results by worksite by component for a given time period
Samples Flagged for Coolant	 Displays samples flagged for coolant including sodium, potassium and glycol levels for a given time period

Diagnostic Report Descriptions (2 of 2)



Generating Reports (1 of 2)

				_	Select Language
ABCHECK NEXTGENERATION	ABCD Results by	Component	×	Frank Gilboy → Last login o	
HOME SAMPLES EQUIPMENT LABELS					Quick Search
	Filters				
Management Distributions	Select Filter 🔻	+ 0		- 10	
	Start Date*	End Date*			
	02/04/2015	02/04/2016			
Management Reports	🗹 🛋 Acme Waste,	Potsdam, NY			
Transit Time Summary					Unregistered Units and Component
	4	Display Report	Clear Selections	Close	
Components With No Product In Use					Sample Labels
	Contraction of the second s				

Diagnostic Reports



First select the date range by selecting the **Start** & **End Date** Next select the **check box** next to the worksite(s) or locations you want to include. Once your selections are made, click **Display Report.** You can save selections for future use by clicking on the green "+" Add Filter button. *Note: For more detailed instructions, view the Filters quick start guide*

Generating Reports (2 of 2)



Printed On: 01/14/16 Date Range: 01/14/15 - 01/14/16

To PDF



A new window will open with your management report. *Note: If the report does not appear after clicking* **Display Report,** please make sure that your pop-up blocker is turned off. To print or save your report, click on the "To PDF" button in the upper right corner of this page. Your report will then open in a PDF format.



Company Name Component

Acme Waste



LABCHECK SUPPORT DESK:

Phone: 1.866.522.2432

Email: LabcheckSupport@AnalystsInc.com

www.LabcheckResources.com