

# Quick Start Guide Printing Reports

Learn How To:

1. Print/Download Multiple Reports

HOME	SAMPLES	EQUIPMENT	LABELS	REPORTS	PREFERENCES	S ADMIN								
Inbox	Search	etails Histor	v											
			·											
<b>∧</b> Tre	end Graph	Send Email	Dow	nload PDF	Include in PDF Rep	oort: 📃 Graphs	Images Comments Actions							
-Labcheck	s Support			1				Condition:						
		Account	Information	1			Sample Information							
		Customer ID#	£ 199306			Lab No.: 201606170117								
		Company Name	e: Acme Equi	ipment		Sample Tracking #: P201510306975								
	C	Company Worksite	e: Worksite #	1			Sample Date: Jun 13, 2016							
	(	Company Address	. 10770 Vine	ecrest		Received Date: Jun 17, 2016								
		Sompany Address	" Houston, T	X, 77086										
		Unit Ir	formation				Component Information							
		Unit I	): 1300				Cpnt. Description: ENGINE							
		Unit Mfg	j: Autocar			Cpnt. Mfg: Cummins								
		Unit Mode	I: ACX64			Cpnt. Model: ISM-350V								
		Unit Serial #	: 5VCACLK	F4AH210833			Cpnt. Serial #: Unknown							
		Unit Worksite	: Roxanna	LANDFILL			Cpnt. Type: ENGINE							

### Maintenance Recommendations for Lab No.: 201606170117

### Evaluated By: Gibbons, Timothy

Increased nitration can cause the formation of acid in the oil, along with possible increase in viscosity. Check for proper operating conditions.--RECOMMENDATIONS --Sample results indicate presence of contamination and/or wear. For a more indepth review, refer to compartment history, trend graph or other Labcheck tools. A resample of the compartment will

help confirm r applicable, pe

To *Print* a report from the *Details screen*; click the **Download PDF** button.

nge oil, and filters (if applicable), to remove contamination. If

### **Printing Reports**

Account Information	Sample Information	Other Sample Information
Customer ID#: <u>199306</u>	Lab No.: 201606170117	PO No.:
Company Name: Acme Equipment	Sample Tracking #: P201510306975	Work Order No.:
Company Worksite: Worksite #1	Sample Date Jun 17, 2016	
Compony Address 10770 Vinecrest	Received Date: Jun 17, 2016	
Houston, TX, 77086	Completed Date: Jun 17, 2016	
Unit Information	Component Information	Fluid Information
Unit ID: <u>1300</u>	Cpnt. Description: ENGINE	Fluid Manufacturer: CASTROL
Unit Mfg: Autocar	Cpnt. Mfg: Cummins	Fluid Brand/Product: HYPURON ADV FORMULA
Unit Model: ACX64	Cpnt. Model: ISM-350V	Fluid Grade: 10W30
Unit Serial #: 5VCACLKF4AH210833	Cpnt. Serial #: Unknown	
Unit Worksite: ROXANNA LANDFILL	Cpnt. Type: ENGINE	

#### Maintenance Recommendations for Lab No.: 201606170117

Evaluated By: Gibbons, Timothy

Increased nitration can cause the formation of acid in the oil, along with possible increase in viscosity. Check for proper operating conditions.--RECOMMENDATIONS --Sample results indicate presence of contamination and/or wear. For a more indepth review, refer to compartment history, trend graph or other Labcheck tools. A resample of the compartment will help confirm results. When C or D codes are present, the following is recommended, if not done at time of sampling. Change oil, and filters (if applicable), to remove contamination. If applicable, perform off-line filtration if available. Closely monitor unit and resample at one-half the normal service interval.

SPECT	SPECTROCHEMICAL ANALYSIS IN PARTS PER MILLION																								
W									ear Metals						Contaminants					Additives					
LA	в).	SAMP	LE /N	tron	Chromium	Nicke,	Auminum	head	Copper	Tin	Silver	Titanium	Silicon Sodium Potassium Boron Molybdenum Phospiorus Zinc Calcium Phospiorus Zinc Calcium								Vanadium				
011	.7	06/13/	16	25	<1	<1	2	3	4	<1	<0.1	<1													
120	)4	01/07/	16	41	2	<1	2	9	6	<1	< 0.1	<	A no		inda		llon		with H	tha E		voro	on o	,t	
083	8	11/06/	15	28	1	<1	2	5	5	1	< 0.1	<	Апе	VV VV	IIIUU	VV VV	πορ		VILII	пег		versi		2	
015	52	09/08/	15	58	3	<1	4	26	8	<1	< 0.1	<				-									
133	33	07/10/	15	46	2	<1	3	9	6	1	<0.1	<	vour	rep	ort. I	lo pr	int s	sele	ct th	e Pr	int ic	con c	or on		
149	99	05/04/	15	32	1	<1	<1	4	4	<1	< 0.1	<	<i>J</i> • • • •	·•P		· • p.	,			••••					
													VOUR	kov	hoar	d ha		$\alpha u n$	tha	<b>CTE</b>	D hi	itton	and	tha	
SAMPL	E INFO	RMATION						FLUID I	PROPERT	TES/CON	TAMINA	NTS	yuu	rey	DUal	u nu	JU U		แษ			ποπ	anu		
LAB NO.	SAMP	VN TIME	FLU		M FILT	ER LU . SER	IBE VICE	Viso 10	cosity 0 °C	V Gr	Visc Grade A			letter <b>P</b> at the same time.											
0117	06/13	/16 4080	5 308	41 HR	No No		S	1	2.1	3	30														
1204	01/07	/16 1353	5 357	71 HR	No		S	1	2.1	- 3	30	0.													

0.2

0.7

0.3

0.2

16

21

19

16

KEY: UoM - Unit of Measure	Y - YES	N - NO	C - CHANGED	>
----------------------------	---------	--------	-------------	---

3129

2681

2256

0838

0152

1333

11/06/15 13094

09/08/15 12646

07/10/15 12221

1499 05/04/15 11745 1780

Testing performed by Bureau Veritas®, an ISO/IEC 17025:2005 accredited laboratory L-A-B Accredit Notice: This analysis is intended as an aid in predicting mechanical wear. Test results, maintenance expressed or implied, is made against failure of this piece of equipment or a component thereof. The

HR

HR

HR

HR

No

No

No

No

s

S

S

S

11.5

12.1

12.1

12.1

1

30

30

20

ory and apply on to this sample as provided. No guarantee, a equipment owner.

<1.0

<1.0

<1.0

<1.0

5.55

3.81

5.11

4.71

< 0.1

< 0.1

< 0.1

< 0.1

NEG

NEG

NEG

NEG

11

13 B

12 B

10

## Printing Reports

							Fran	Select nk Gilboy <del>v</del>	t Language Last logir	English•		
	HOME SAMPLES	equipment labels re	Ports Pref	FERENCES ADMIN			Qui	ick Search		Need Help?		
nbox	Search						Ļ					
Date R	ange: Last Year	• Show: All	• 🗙	Clear from Inbox	Export XI	s	Print Report	(s) <b>0</b> S	how/hide	columns		
	Severity	Condition	U	nit ID Un	it Serial No.	С	component	Make / N	Seri			
	D	Coolant Additives	WP24	17017	8	ENGINE		Caterpillar	170178			
	В	Oxidation	WP26	17018	0	ENGIN	IE	Caterpillar	MXS699			
	Α	Acceptable	ED601			ENGIN	IE	Caterpillar	/ D6NXL	AKM004:		
	В	Low Viscosity	L1803			TRANS	S-AUTO	Caterpillar	T8CR032			
	Α	Acceptable	LB 104			ENGIN	IE	Caterpillar	r			
	D	Viscosity/Wear	EX305	DKY00	657	HYDR/	AULIC	Caterpillar				
个	Α	Acceptable	EX104	CJC02	889	HYDRAULIC		Caterpillar	/ 315CL			
D	Α	Acceptable	L1803			ENGIN	IE	Caterpillar	/ IT28G			
	Α	Acceptable	EX201	To Prin	<b>f</b> one or m	nultir	ole reports :	from the	e Sam	ole Inbox.		
	Α	Acceptable	TT304	Advanc	ed Search	se	lect the che	eck box	es next	to the		
	Α	Acceptable	EX201	sample	samples and click the <b>Prin</b>			Report(s) button				
	۸	Acceptable	LB 104									

### **Printing Reports**

Account Information	Sample Information	Other Sample Information
Customer ID#: 199306	Lab No.: 201606170117	PO No.:
Company Name: Acme Equipment	Sample Tracking #: P201510306975	Work Order No.:
Company Worksite: Worksite #1	Sample Date Jun 17, 2016	
Company Address 10770 Vinecrest	Received Date: Jun 17, 2016	
Houston, TX, 77086	Completed Date: Jun 17, 2016	
Unit Information	Component Information	Fluid Information
Unit ID: 1300	Cpnt. Description: ENGINE	Fluid Manufacturer: CASTROL
Unit Mfg: Autocar	Cpnt. Mfg: Cummins	Fluid Brand/Product: HYPURON ADV FORMULA
Unit Model: ACX64	Cpnt. Model: ISM-350V	Fluid Grade: 10W30
Unit Serial #: 5VCACLKF4AH210833	Cpnt. Serial #: Unknown	
Unit Worksite: ROXANNA LANDFILL	Cpnt.Type: ENGINE	

#### Maintenance Recommendations for Lab No.: 201606170117

Evaluated By: Gibbons, Timothy

Increased nitration can cause the formation of acid in the oil, along with possible increase in viscosity. Check for proper operating conditions.--RECOMMENDATIONS --Sample results indicate presence of contamination and/or wear. For a more indepth review, refer to compartment history, trend graph or other Labcheck tools. A resample of the compartment will help confirm results. When C or D codes are present, the following is recommended, if not done at time of sampling. Change oil, and filters (if applicable), to remove contamination. If applicable, perform off-line filtration if available. Closely monitor unit and resample at one-half the normal service interval.

SPECT	SPECTROCHEMICAL ANALYSIS IN PARTS PER MILLION																								
							W	ear Metals						Contaminants						Additives					
	в	SAMPLI	E	tron	Chromium	Nicke,	Aluminum	Lead	Copper	Tin	Silver	Titanium	silicon	Sodium	Potassium	<sup>Boron</sup>	Molybdenur	Phosphorus Zinc	Calcium	<sup>Barium</sup>	Magnesium	<sup>Ant</sup> imony	Vanadium		
011	7	06/13/1	6	25	<1	<1	2	3	4	<1	<0.1	<													
120	4	01/07/1	6	41	2	<1	2	9	6	<1	<0.1	<	Δno	\ <u>\</u> / \\/	indo	<b>M/ M/</b>	ll on	on with	tha F		vorei	n n n	f		
083	8	11/06/1	5	28	1	<1	2	5	5	1	< 0.1	<		<b>VV VV</b>	nuo	<b>VV VVI</b>	n ob				V CI SI				
015	2	09/08/1	5	58	3	<1	4	26	8	<1	<0.1	<		-	~ -+ T		int .	a ala at t		int is		-			
133	3	07/10/1	5	46	2	<1	3	9	6	1	< 0.1	<	your	repo	JIL I	0 pr	IIII, S	select l			2011 O				
149	9	05/04/1	5	32	1	<1	<1	4	4	<1	< 0.1	<	<b>1</b>												
													VOUr	kev	boar	id ho	old d	own the	e CTF	RL bi	utton	and	the		
SAMPL	LE INFORM	ATION						FLUID F	PROPERT	IES/CON	TAMINA	NTS	<b>J C C i</b>			<b>..</b>									
LAB	SAMPLE	UNIT	FLUI		FILTI	ER LU	BE	Viso	osity	V	isc		latta	r <b>P</b> a	t the	a car	no ti	mo							
NO.	DRAWN	TIME	TIME	E	CHG	. SER	VICE	10	0 °C	Gr	ade	Α	ICIC			5 301		inie.							
0117	06/13/10	40806	3084	1 HR	No	9	5	1	2.1	3	30														
1204	01/07/10	5 13536	3571	HR	No	9	S	1	2.1	3	30	0.	3	19		12 8	5	NEG	< 0.1	<1.0	)	5.39			
0838	11/06/1	5 13094	3129	HR	No	9	5	1	1.5	3	30	0.	2	16		11		NEG	<0.1	<1.0	)	5.55			
0152	09/08/15	12646	2681	HR	No	9	5	1	2.1	1 30			7	21		13 B	3	NEG	< 0.1	<1.0	)	3.81			

0.3

0.2

30

19

16

#### KEY: UoM - Unit of Measure Y - YES N - NO C - CHANGED > -

2256

1780

1333 07/10/15 12221

05/04/15 11745

1499

Testing performed by Bureau Veritas®, an ISO/IEC 17025:2005 accredited laboratory L-A-B Accredite Notice: This analysis is intended as an aid in predicting mechanical wear. Test results, maintenance expressed or implied, is made against failure of this piece of equipment or a component thereof. The

HR

HR

No

No

S

S

12.1

12.1

1

ory and apply on to this sample as provided. No guarantee,

<1.0

<1.0

5.11

4.71

< 0.1

< 0.1

NEG

NEG

12 B

10



### LABCHECK SUPPORT DESK:

Phone: 1.866.522.2432

Email: LabcheckSupport@AnalystsInc.com

### www. LabcheckResources.com